

Cleaning the screen – Espresso Machine, SB1200

FRANKE

1) Tap the McCafe' logo at the top left of the screen.




2) Enter the PIN code 1111 and tap **OK**




3) Select Cleaning and Maintenance, then select Wipe Protection.

The user interface is locked for 20 seconds.



4) Clean the surface with a clean, sanitizer-soaked towel.



END